

UV curing process with UVH-255



Starting pack information

Before first use, please read the instruction manual carefully and mount the handle. For safety, technical and guarantee reasons, use the lamp only in combination with Panacol original spare parts.

Please follow our recommendations:

Choose your language in the CD Rom



- ✓ For reliable curing of the primer, **change the bulb after 500 hours**
- ✓ Use original Panacol 250W spare bulb, in order to keep your warranty claim.



- ✓ For safety reasons, UV protective glasses must be used.
- ✓ Curing result depends on time, use Panacol UV timer.



- ✓ Change blue glass filter, in case of failure.
- ✓ For safety reasons, **never** use the lamp **without** Panacol blue glass filter.



- ✓ To avoid overheating, change regularly Panacol dust filter.
- ✓ A routine maintenance allows a longer lamp life time.



- ✓ To make work easier and more reliable, use our trolley mounting lamp stand